

swimming pool cover
Assembly manual(ModelD)


L10868*W6183*H1771




Part Code		Quantity	Part Code		Quantity	
1	D1-001	6	16	2000mm	2	
2		20	17		12	
3		5	18		4	
4		5	19		1	
5	2183*1070*T3	6	20		1	
6	♦ ०, ० ♦ M6 holes	15	21		120	
7	. O O O O O Without M6 holes	15	22	·	120	
8	M6*35	60	23	6	20	
9		10	24	(→ MMMMM ST4. 2*20	20	
10	4.0*8	204	25	@	20	
11	ST5. 5*50	74	26	D1-002	6	
12	ry and the same of	30	27	2247*1070*T3	6	
13		1	28	D1-003	6	
14		1	29	2312*1070*T3	6	
15	23200mm	6				2


Part Code		Quantity	Part Code		Quantity
30	D1-004	6	42		3
31	2376*1070*T3	6	43		3
32	D1-005	6	44		2
33	2441*1070*T3	6	45		2
34		1	46	M6*40	3
35		1	47	M6*50	8
36	4.0*16	4	48	M10	4
37		1	49	M6	8
38		2			
39		6			
40	(So So	3			
41		3			3








II:Arch & PC Sheet Assembly

























cut item 20 in suitable length, and put them in the gap between PC sheet and aluminum profile, and then use something flat tool to put all the rubber seal strip inside the gap deep so that you can't see it. Probaly, you need to see see the door item 13 how to put the rubber seal strip inside





The mounting steps for Frame B/Fram C and FrameD is same. Don't forget to mount item 19 first in one of the set when you mount Frame C and D.


Frame C




Only this arch need to mount item 19 first when you mount the entire Frame C











Drill Ø4.8 holes first in the Frame A along the current hole and then Mount the half door (13/14)to the Frame A with the screw ST 5.5*50(item 11)















Item 43 is mounted on the ground, you need to drill a hole, and then put 43 in it, 43 and 42 must be in a line, so that 42 can put in 43 to lock the door.







Drill Ø4.8 holes first in the Frame E along the current hole and then Mount the half door (34)to the Frame E with the screw ST 5.5*50(item 11)








These parts are mounted outside of the door. You need to cut the dust cloth, so that the wheels can be used





Item 39 is mounted on two sides of these arch, so that you can pull the swimming pool cover.